



**RECESS MOUNTING
INSTRUCTIONS FOR**

Gilbert®

MODELS 601C & 601E

1. The opening to be cut in the wall should be approximately 12" above floor level.
Cut the opening 53 1/8" high by 16 1/8" wide.
2. Install a fire block at the top and bottom of the opening and cut a hole in the top block for the power supply to pass through.
3. Remove the inner body from the unit by removing the two sheet metal screws on each side of the wing nut below the electrocutor grid. Remove the wing nut and slide the inner body down and out.
4. Place the outer case in the opening allowing the 11/16" lip to protude from the wall.
5. Drill holes in the top and bottom of the outer body and secure to the fire blocks with screws.
6. Outer case may be trimmed around protuding lip with standard moulding for finished appearance.
7. Connect power supply, insert inner body and secure with wing nut.